



Use and Care Guide
**Waffle Baker &
Sandwich Toaster**

MODEL **CG120**



P.N. 114678

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not place product or electric cord in water or other liquid. See instructions for cleaning.
- Close supervision is necessary when any appliance is used by or near children.
- Do not leave appliance unattended.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service center for examination, repair or adjustment.
- To reduce the risk of injury, use only manufacturer-approved accessory attachments.
- Do not use outdoors or while standing in a damp area.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance except as intended.

THIS PRODUCT FOR HOUSEHOLD USE ONLY
SAVE THESE INSTRUCTIONS

USING YOUR APPLIANCE

1. Plug into any 220-volt AC outlet. Turn control knob to highest setting. Initially, some smoking may occur. This is normal for newly manufactured appliances and will not recur after the first few uses.
2. Lightly coat cooking surfaces with oil and close lid.
3. When indicator light goes off, immediately raise lid and pour approximately 2/3 cup batter on lower grid. Close the lid. The amount of batter required may vary with recipe or brand of mix.
4. When light goes off the second time, gently lift lid to check for brownness. If lid shows resistance to lifting, the waffle may not be quite done. Close top and watch for steaming to stop before checking again.
5. Remove waffle when browned. If a second waffle is desired, pour batter immediately and close lid. If you prefer a darker and crisper waffle, close lid and let cook 1-2 minutes longer. For a lighter, airy one, turn control knob to lowest setting, unplug and cool before cleaning.
6. When finished baking, turn control knob to lowest setting, unplug and cool before cleaning.

CONDITIONING COOKING SURFACES

The cooking surfaces require conditioning before each heating that follows washing. To condition: spray or brush the cooking surfaces with cooking oil. Set control knob to recommended cooking temperature. When indicator light goes off, unit is preheated. The cooking surfaces are ready to use.

To protect the premium quality non-stick cooking surfaces use only plastic, nylon or wooden utensils. Carefully follow the suggested cleaning procedures listed below.

TO CLEAN

Caution: Unplug from electrical outlet before cleaning. **Never immerse appliance in water.**

- While the cooking surfaces are still warm, brush with clean, soft pastry brush or cloth.
- Do not use steel wool or coarse scouring pads. Remove stubborn stains with a plastic mesh puff or pad. For best results, use only products with directions stating safe for cleaning non-stick surfaces.
- The exterior finish should be cleaned with a non-abrasive cleaner and soft, damp cloth.

Any servicing requiring disassembly should be performed by an authorized OSTER® service center.





Manual de Uso y Cuidado
**Waflera &
Sandwichera**

MODELO CG120



P.N. 114678

IMPORTANTES MEDIDAS DE SEGURIDAD

Cuando use aparatos eléctricos, tenga las siguientes precauciones:

- Lea las siguientes instrucciones detenidamente.
- No toque superficies calientes. Use las agarraderas.
- Para evitar choques eléctricos no sumerja el producto o el cordón en agua u otro líquido. Lea las instrucciones para su limpieza.
- Es necesaria la supervisión de un adulto cuando el aparato es usado por niños o cerca de ellos.
- No deje el aparato funcionando sin alguna supervisión.
- Desconéctelo del tomacorriente cuando no esté usando el aparato, cuando esté poniendo o quitando alguna parte o para limpiarlo.
- No opere el aparato con el cable dañado o con algún defecto de funcionamiento. Llévelo al Centro de Servicio Autorizado más cercano, para que éste sea examinado y reparado.
- El uso de accesorios no vendidos o recomendados por el fabricante puede ser peligroso.
- No lo use a la intemperie, o mientras esté parado sobre suelo o piso húmedos.
- No permita que el cordón cuelgue del borde de una mesa o que toque alguna superficie caliente.
- No coloque el aparato sobre o cerca de una hornilla de gas o electricidad, ni de un horno caliente.
- Use extrema precaución cuando esté moviendo el aparato y éste contenga algún líquido caliente.
- Use este aparato sólo para su propósito.

**ESTE PRODUCTO ES PARA USO DOMÉSTICO SOLAMENTE
CONSERVE ESTAS INSTRUCCIONES**

FORMA DE USAR SU APARATO

1. Conéctelo a un enchufe de 220 voltios. Gire el botón del control hasta la temperatura más alta. Las primeras veces que lo use, es posible que le vea salir un poco de humo: esto es normal y se le quitará en cuanto lo haya usado varias veces.
2. Póngales una capa delgada de aceite a las planchas de cocción y ciérrelas.
3. Cuando la luz indicadora se apague, levante inmediatamente la tapa y vierta aproximadamente 2/3 de taza de mezcla en la parte inferior. Cierre la tapa. La cantidad de mezcla depende del tipo de receta o del tipo de mezcla.
4. Cuando la luz se apague por segunda vez, levante la tapa cuidadosamente, cerciórese de que la mezcla esté dorada. Si nota que al levantar la tapa la mezcla queda semipegada a ella, el waffle no está listo. Cierre la tapa de nuevo, y espere a que el vapor deje de salir antes de volver a abrir.
5. Remueva el waffle cuando esté dorado. Si desea otro waffle, vierta la mezcla inmediatamente y cierre la tapa. Si prefiere el waffle más oscuro y tostado cierre la tapa y déjelo cocinar por 1 ó 2 minutos más. Si desea el waffle menos dorado, gire el control a una temperatura más baja.
6. Cuando haya terminado de hornear, gire el control hasta la temperatura más baja, desconéctelo y deje enfriar antes de limpiar.

CÓMO ACONDICIONAR LAS PLANCHAS DE COCCIÓN

Las superficies de las planchas de cocción deben ser engrasadas cada vez que el aparato vaya a ser usado. Para engrasar: unte un poco de aceite de cocinar en las planchas de cocción. Coloque el botón de control en la temperatura recomendada. Cuando la luz se haya apagado, las planchas de cocción están listas para ser usadas.

CÓMO LIMPIAR SU WAFLERA

Precaución: Desconecte de la electricidad antes de limpiar. **Nunca sumerja el aparato en agua.**

- Mientras las planchas de cocción estén tibias, páseles un paño limpio.
- No use estropajo de aluminio ni esponjas ásperas. Remueva los residuos difíciles de quitar con estropajo plástico. Para un mejor resultado use solamente productos específicamente hechos para limpiar superficies antiadherentes.
- El exterior del aparato debe asearse con un limpiador no abrasivo y con un paño húmedo y suave.

Si su aparato requiere algún servicio o desensamblaje, éste debe ser realizado en un Centro de Servicio Autorizado de Oster®.

